





VIEW A






SECTION B-B




DETAIL G




Working range based on point P




Base Installation Dimensions




VIEW C




VIEW D-D



VIEW E-E



VIEW F



KF192  
WORKING RANGE